


PIASINI

engineering



ECU : MAGNETIMARELLI IAW-59F/5AF




Pin out - Front view :


Plug 1:

- Pin 10 Ground
- Pin 34 Ground
- Pin 4 Power Supply
- Pin 17 Power Supply
- Pin 16 K line

Now you can pierce the Ecu (picture 1) or you can open it (picture 2) for find the Bootstrap's pin.



Picture 1



Picture 2

BootStrap's Pin:



Now you can see some wires and one pit that's without wire, this is the Bootstrap's pin, you have to connect to the ground to qualify the reading of ECU, then supply the ECU and when you click on the Identify Button remove this pin from the ground