


PIASINI

engineering



ECU : Delphi DCM 1.2




Pin out - Front view :

Plug 3:

Power Supply
Ground
K line

Pin G1
Pin H1
Pin B4

Now you must pierce the Ecu



Bootstrap's Pin:

The **blue pin** is the Bootstrap's Pin, you have to connect to the ground to qualify the reading of ECU; then supply the ECU and when you click on identify button remove this pin to the ground