


ECU Write:



Connect as below:

Serial Suite:

ECU Plug:

Red  
Black

to  
to

2 Pins Red (Power Supply +12 Volt)  
1 Pins Black (Ground)

You have to connect the wire of flat cable like in the picture.

