


ECU Write:



Serial Suite: ECU Plug:

Red to 2 Pins Red (Power Supply +12 Volt)
Black to 1 Pins Black (Ground)

You have to connect the wire of flat cable like in the picture.

