


ECU Write:



Connect as below:

Serial Suite:

ECU Plug:

Red	to	2 Pins Red (Power Supply +12 Volt)
Black	to	1 Pins Black (Ground)

You have to connect the wire of flat cable like in the picture.

