

Connect as below:


Serial Suite:

Red
Black

to
to


ECU Plug:

1 Pins Red (Power Supply +12 Volt)
1 Pins Black (Ground)




WARNING:

Make the hole NO deeper than 7mm !



How to connect the flat cable for **READING**



You have to connect the flat following the numbers like in the picture.