



Connect as below:

Serial Suite:

ECU Plug:

Red	to	1 Pins Red (Power Supply +12 Volt)
Black	to	2 Pins Black (Ground)
Green	to	1 Pin Green (K Line)
Yellow	to	1 Pin Yellow (Flash Voltage)

