


Connect as below:


Serial Suite:		ECU Plug:
<mark>Red</mark>	to	1Pins <mark>Red</mark> (Power Supply +12 Volt)
Black	to	2 Pins Black (Ground)
Green	to	1 Pin Green (K Line)
Yellow	to	1 Pin <u>Yellow</u> (Flash Voltage) - See Below



How to connect the Yellow banana

WARNING:

Make the hole NO deeper than 3mm !



You have to connect the yellow banana of Serial Suite to P1 through the metal point. Holding connect the metal point for all time, during the connection and when you reading the Ecu. NEVER Remove the metal point for the whole procedure (Identify, Read and Write).