


ECU Write MICRO1:



Connect as below:

Serial Suite:


Red
Black

to
to


ECU Plug:

2 Pins Red (Power Supply +12 Volt)
2 Pins Black (Ground)

You have to connect the wire of flat cable like in the picture.



ECU Write **MICRO2**:



Connect as below:

Serial Suite:

Red
Black

to
to

ECU Plug:

2 Pins **Red** (Power Supply +12 Volt)
2 Pins **Black** (Ground)

You have to connect the wire of flat cable like in the picture.

